

INTERMEDIATE



The Intermediate is designed to be installed on the Cone. It is a cable support used at specific intervals and due to its design, the Scope Shuttle can easily slide over it without disconnecting it from the lifeline.

INTERMEDIATE



Cleaning & maintenance

Products do not require any special maintenance, aside from cleaning. Cleaning of your SDA product is important to prolong its lifetime. Use cold water and soap to eliminate all type of residue (dirt, chemicals, etc.). Dry gently out of sunlight. After use, place your product in a well-ventilated area and avoid excessive heat. Proper care prevents premature wear of the equipment.

Inspection

Look for damage, deterioration or malfunction before and after every use. Inspections should only be made by trained and authorized personnel. Every inspection should be registered in the product dossier.

Weight :	Breaking Strength :	Anchorage :	Dimensions :	Marking :
0,29 kg.	25 kN	Safety nut	Width: 115 mm Height: 58 mm Depth: 70 mm	Serial number on safety nut

Packaging :	Intermediate :	Surface Treatment :	Color :
Pre-installed with the post / Unit per plastic bag	Stainless Steel 316	Electropolished	Chrome