

OVERHEAD END POINT



The End Point is the connection between the line system and the structure. It is designed for easy installation on steel/concrete beams and structures of sufficient strength. The End Point is designed to rotate and always be in line with the cable, which results in minimal shear stress in case of a fall.

OVERHEAD END POINT



Cleaning & maintenance

Products do not require any special maintenance, aside from cleaning. Cleaning of your SDA product is important to prolong its lifetime. Use cold water and soap to eliminate all type of residue (dirt, chemicals, etc.). Dry gently out of sunlight. After use, place your product in a well-ventilated area and avoid excessive heat. Proper care prevents premature wear of the equipment.

Inspection

Look for damage, deterioration or malfunction before and after every use. Inspections should only be made by trained and authorized personnel. Every inspection should be registered in the product dossier.

Weight :	Breaking Strength :	Anchorage :	Dimensions :	Marking :
0,51 kg.	25,0 kN	Safety nut	Width: 42 mm Height: 103 mm Depth: 75 mm	Batch Number

Packaging :	End Point :	Surface Treatment :	Color :
Unit per plastic bag	Stainless Steel 316	Electropolished	Chrome